



POWER SUPPLY			
VOLTS	230VAC	Hz	50
MAX MOTOR LOAD			
WATTS	500	AMPS	2.1
PROTECTIVE FUSE			
F1 - 4	5A		
OPERATING TEMP RANGE			
°C	-40 TO +85		

**Instructions**

1. Connect a suitable 230v AC mains supply to **"POWER"** terminals
2. Connect all 230v AC tubular type motors to connections **"MOTOR 1 - 4"** as shown
3. Connect either key-switch or push button station to **"MOTOR CENTRAL"** terminals to control all shutters simultaneously **and/or** **"MOTOR MANUAL"** terminals for individual shutter operation

**Any unused stop circuits must be bridged between STOP and COM**

Optional Accessory Transmitter  
 AC129 4Channel Transmitter (Not supplied with unit)  
 (Max no 5 transmitters per channel)

**To Program**

Select channel using **⏪** **⏩** buttons

Ch1 ■■■■  
 Ch2 ■■■■  
 Ch3 ■■■■  
 Ch4 ■■■■  
 Group ■■■■

Press Required Channel button on the receiver - **ONCE** only

Press **⏪** button, receiver LED will confirm acceptance

Micro USB to recharge

**To Delete Transmitters**  
 Press and hold channel button on the receiver unit until the channel light flashes quickly, release button and quickly press once more transmitter are now deleted

*This drawing is the property of ELLARD LTD, it may not be reproduced without the written authorization of Ellard Limited. All intellectual property rights are expressly reserved*

**ELLARD**  
 Roundthorne Industrial Estate  
 Ellard House, Floats Road  
 Wythenshawe, Manchester  
 M23 9WB  
 Tel: 0161 945 4561, e-mail: technical@ellard.co.uk

Title  
**EASY GROUP  
 (4 WAY TUBE MOTOR  
 GROUP CONTROLLER)**

Rev/Notes

<u>Date</u>	01/02/2022		
<u>Drawn by</u>	DE	<u>Chk'd by</u>	AP
<u>Drg #</u>	EASY GROUP - General Set Up		